


This quick reference gives you an overview of the functions of the Thomas & Betts ELZ500 Professional Labeling System. For more detailed information on using your EZL500 Professional Labeling System, please refer to the EZL500 Instruction Manual or visit our website at www.tnb-id.ca.



EZL500 Professional Labeling System Hot Key Quick Reference

FIXED MODE			
		0.75"	
LENGTH		1.00"	
		1.25"	
1.24	2.50	1.75	DONE

1. Press
2. Enter the length + or
3. Input text
4. Press

PPANEL MODE		
# ROWS	# PORTS	WIDTH
1		
2	6	1.00"
		SEL

1. Press
2. for row +
3. for port +
4. for width +
5. Input text
6. Press

VWRAP MODE			
DIA	1mm		
	2mm		
INCH	MM	GAGE	DONE

1. Press
2. Enter the diameter + or
3. Input text
4. Press

FLAG MODE			
		0.75"	
LENGTH		1.00"	
		1.25"	
1.00"	8.5"		DONE

1. Press
2. Enter the length + or
3. Input text
4. Press

TBLOCK MODE		
# COLUMN	# BLOCK	HEIGHT
1		
2	6	1.00"
		SEL

1. Press
2. for column +
3. for block +
4. for height +
5. Input text
6. Press

HWRAP MODE			
LENGTH		1.00"	
		1.25"	
1.00"	8.5"		DONE

1. Press
2. Enter the length + or
3. Input text
4. Press

Saving/Recalling

1. Press

A	B	C	D	E	F	G	H	J	K
L	M	N	O	P	Q	R	S	T	U
M:	<EMPTY>								
SAVE									

2. To save, select an empty bay (not bold) and press SAVE

A	B	C	D	E	F	G	H	J	K
L	M	N	O	P	Q	R	S	T	U
EZL-WP12	ACHTUNG!								
		RCL	DEL						

3. To recall, select the bay and press RCL (recall). This label overwrites current label. So save before recalling.

Serialization

1. Press

A1	
SERIALIZATION SINGLE	
	NEXT

2. Select Letter. Press NEXT or

Character Increment	1
	2
HELP	NEXT

3. Use arrows or directly input increment, which is the difference between the 1st and 2nd label.

Press NEXT or

Number of Labels	5
	6
	7
	DONE

3. Use arrows or directly input number of labels.
4. Press DONE or

Barcode

1. Press

Code 39	Code 128
EAN 13	UPC A
EAN 8	UPC E
	DONE

2. Use arrow keys to select type.
3. Press DONE or
4. Barcode will be bordered by